

STEP 1

Scan QR code below

Get started by scanning code or visiting www.versahub.com/setup/versatile/ to begin device setup.

Visit [versahub.com](http://www.versahub.com) for setup video instructions, troubleshooting, and guides.



STEP 2

Follow device setup on VersaHub™

IMPORTANT

During setup, place your VersaTile in its intended location. While connecting device to your WiFi it will indicate signal strength. Ensure a strong WiFi connection is available with 4 bars (recommended) or greater.

SSID	Signal	Enc.
TP-Link_27a		WPA/WPA2/PSK



STEP 3

Setup Notifications & Alerts

After completing setup, configure alert thresholds in device settings panel.

INSTALLATION TIPS

Install VersaTile as high as possible to avoid being surrounded by containers of food/water/etc., which can impede WiFi connection.

VersaTile is provided with a sticky mounting tab. Prior to installing, ensure surface is clean and free of any moisture.

VersaTile has excellent battery life, but can be plugged into a USB-C charger for fast sync and recording intervals.

Questions?

www.versahub.com/setup/versatile/

Quick Start Guide

Before you begin, you will need:

- VersaTile™
- A smartphone (recommended), tablet, or PC with WiFi
- Your location's WiFi network name & password. (2.4GHz network required)



Warranty: Two (2) years of limited warranty. (Batteries and physical damages are exempt from the warranty.)

